

RBT

Riser Break-out Tool

Instruction Sheet

Warning! This tool should not be used on live electrical circuits. It is not protected against electrical shock! Always use OSHA/ANSI or other industry approved eye protection when using tools. This tool is not to be used for purposes other than intended. Read carefully and understand instructions before using this tool.

The Miller® RBT Riser Break-out Tool is designed to cut an access window in 8.5mm, 10.5mm, and 14mm riser cable jackets without adjustment.

Tool features:

- Lightweight aluminum body construction
- Fits into small areas for closely packed riser cables
- Can be used on cable mounted directly to wall
- Blade is recessed for user safety
- Easily replaceable blade with no adjustments
- Tool dimension: 100mm x 38mm x 17mm Weight: 0.1kg



Operation:

1. Grasp the tool in the area of the window cut, applying forefinger pressure on the cable against the blade. (Fig.1)
2. Draw the tool in the direction of the desired window holding pressure against the cable. (Fig.2)
3. To terminate the window cut, lift the back end of the tool until the window chip breaks off (Fig.3)
4. The low profile design also allows for tool operation on a face mounted cable. (Fig.4)




Fig.1




Fig.2




Fig.3




Fig.4

WARRANTY: RIPLEY warrants its products against defective materials and workmanship for a period of one year from date of shipment from the RIPLEY factory provided the product is utilized in accordance with instructions and specified ratings.



46 Nooks Hill Road, Cromwell, CT 06416 USA ~ Phone: 800-528-8665 ~ Int'l: (01) 860-635-2200
Fax: (01) 860-635-3631 ~ E-mail: info@ripley-tools.com ~ Internet: www.ripley-tools.com



81317 rev1
12-01-12 ff